






A52P4












8x




4x



24x




24x




22x




20




6x




6x



2x





2x





1x
























12









A



B




C




KOLEJNOŚĆ MONTAŻU
MIMOSRODOW I KOLKOW.
THE FITTINGS SEQUENCE OF THE
CAMS AND DOWELS.
DIE MONTAGEABFOLGE VON
EXZENTERN UND DÜBELN.


1




2




3




4



5



6




Start



Stop

225°


D



E



A5204
A4204



A1104
A1504

